



ASSEMBLY INSTRUCTIONS

TECHART Power-Kit 092 / S1

Part-no. 091.300.520.009 for 992 Carrera S/S4



Version 01 – 09/2019



ASSEMBLY INSTRUCTIONS

TECHART Power-Kit 092 / S1

Content

I.	Important safety information.....	3
II.	Preparation	4
III.	Installation	5
1	Prepare vehicle	5
2	Dismantle original parts.....	6
3	TECHART Plug & Play wiring harness	7
4	TECHART CAN wiring harness.....	9

I Important safety information

All of the necessary work must be performed by qualified persons with an appropriate level of expertise.

	<p style="text-align: center;">WARNING</p> <p>Vehicle lifts with an insufficient lifting capacity can collapse under the weight of the vehicle and crush any persons standing underneath.</p> <p>Compare the weight of the vehicle with the lifting capacity of your vehicle lift. The weight of the vehicle must not exceed the lifting capacity of your vehicle lift. The weight of the vehicle can be found in the vehicle operating manual.</p>	
	<p style="text-align: center;">WARNING</p> <p>Risk of injury from electric current.</p> <p>Switch off the ignition and disconnect the battery when working on the vehicle electrical/electronics systems.</p>	
 	<p style="text-align: center;">CAUTION</p> <p>Risk of injury from hands and arms being crushed, cut or lacerated when working with sharp-edged and bulky objects.</p> <p>Wear protective clothing and protective gloves. Keep limbs out of narrow and inaccessible areas of the vehicle and/or avoid dangerous situations by using special tools and suitable aids.</p>	
	<p style="text-align: center;">CAUTION</p> <p>Risk of injury to back, muscles, joints, tendons and ligaments from lifting and carrying heavy and/or bulky objects.</p> <p>Lift and transport heavy and/or bulky objects with the help of other people and/or with suitable aids.</p>	
	<p style="text-align: center;">NOTICE</p> <p>Before starting the assembly procedure, carefully read the assembly instructions in full and pay attention to the safety information and sequence of the individual operation steps.</p>	

I. Preparation

Number of people required



At least two people are required to install this product.

Help and support

If you have any technical queries, please contact us immediately:
support@techart.de

Check TECHART parts kit for completeness

Quantity	Part number	Part designation
1	092.300.520.009	Techtronic for 992 Carrera S/4S
Consisting of:		
1	000.300.010.105	Techtronic auxiliary control unit ET6
1	092.300.100.200	Cable set Techtronic
1	000.590.501.101	Clip
1	000.300.102.OKT	Octane 100 decal

1. Plug & Play-wiring harness
2. CAN-wiring harness
3. Bracket
4. Octane decal
5. Cable ties
6. Techtronic module




Fig. 01

Please use the table to check whether all of the required parts are present.

Once parts have been removed from their original packaging, ensure that they are properly handled and stored.



ASSEMBLY INSTRUCTIONS

TECHART Power-Kit 092 / S1

II. Installation

1. Prepare vehicle

- i** Before starting to work, check that the vehicle is free of defects. Use the PIWIS system tester to read out all of the fault memories of the individual vehicle components and first rectify any faults displayed.

Please read the assembly instructions thoroughly and observe the specified procedure and instructions. Due to the technical complexity we recommend to let this installation to be carried out solely by an authorized partner. We can only grant guarantee if the installation has been done correctly.

In respect to the driving safety one should inform the customer that the vehicle is equipped with a Techtronic KIT.

2. Dismantle original parts

1. Raise vehicle at the factory-fitted jacking points.
2. Disconnect the battery.
3. Detach the rear spoiler.
4. Dismantle rear apron.
5. Dismantle the DME control unit. For this release all plugs of the control unit, remove the screws and loosen the cable ties.



Fig. 02

3. Install TECHART Plug & Play wiring harness

1. Install the wiring harness beginning with *“pressure before throttle valve”*. For this release and remove the plug. Connect this plug with the TECHART wiring harness (plug *„pressure before throttle valve”*). Connect the plug of the TECHART wiring harness with the sensor.



Fig. 03

2. Route the wiring harness with the plug *“rail pressure right”* (fig. 04) and *“suction pipe pressure”* (fig. 05) to the right and connect with the according sensors.



Fig. 04



Fig. 05



ASSEMBLY INSTRUCTIONS

TECHART Power-Kit 092 / S1

3. Lay the other part of the wiring harness with the CAN plug and "*rail pressure left*" to the left. Connect the rail pressure sensor (fig. 06)



Fig. 06

4. TECHART CAN wiring harness

1. Remove the rear panels in the interior.



Fig. 07

2. Feed a thread help from the left side of the interior through the cable sleeve to the engine compartment. And then pull the CAN-cable into the interior.



Fig. 08

3. Separate the plug from the control unit. Dismantle the plug by pushing the front cover down and pull the pin carrier towards the front.



Fig. 09

8. Reassemble the plug. Connect the 2-pole plug with the TECHART wiring harness in the inside as well as in the engine compartment.
9. Fasten the Techtronic with the attached bracket, as shown on the picture. Fix the wiring harness carefully with cable ties.




Fig. 11

10. Reinstall the DME-control unit. Pay attention that the cable fixation will snap in.



Fig. 12

11. Reconnect the battery, read out the fault memories and if necessary, rectify the faults displayed. After this complete the vehicle.
12. Check, if all components are carefully built in and if they are reliably fastened.
13. Turn ignition on.

14. Depending on the color of the LEDs different operating conditions are shown:
- LED red: Ignition is off or the signals are not recognized completely.
 - LED green: all signals are recognized, tuning is inactive
 - LED blue: engine is warm, Sport mode is recognized, tuning is active.



Fig. 13

15. Recalibrate the rear spoiler and read out the fault memories again and, if necessary, rectify the faults displayed.
16. Perform a test drive and check the vehicle for any faults again.

i The LED status “blue” will be reached after a short drive with permanent engine running.



Fig. 14

- i** The activation of the power increase will be effected by the travel mode-switch at the steering wheel. If the sport-/sport plus mode is not chosen or the sport response button at the normal mode was not pressed then the engine will run with the standard power.
- i** Please consider that the power values of the Techtronic power increase will only be reached with an activated sport mode, operating temperature and a fuel quality of 100 octane.

If these requirements are complied then the power increase will be activated progressively.



ASSEMBLY INSTRUCTIONS

TECHART Power-Kit 092 / S1



TECHART AUTOMOBILDESIGN GMBH

RÖNTGENSTRASSE 47
71229 LEONBERG / GERMANY

TEL +49 7152 / 9339- 0

FAX +49 7152 / 9339-33

info@techart.de

www.techart.de

Subject to change at any time without prior notice.
Copyright 2019 by **TECHART** Automobildesign GmbH