



Montageanleitung

MADE
IN
GERMANY

TECHART – Alupedalsatz Schalt / Tipt. TECHART – Fußstütze für Porsche 996 / 986

Art.Nr.: 086.460.400.009-01
Art.Nr.: 086.460.401.009
Art.Nr.: 086.460.402.009 (LL)
Art.Nr.: 086.460.412.009 (RL)

1. Montage Pedalsatz

- 1.1 Originalen Gummibelag von Kupplungs- und Bremspedal entfernen.
- 1.2 TECHART-Blenden auf die Pedale auflegen, ausrichten, Befestigungslöcher anzeichnen und bohren. (5 mm)
- 1.3 Gaspedalblende an der oberen und rechten Kante des originalen Pedals ausrichten, Befestigungslöcher anzeichnen und bohren. (2 mm)
- 1.4 Pedalblenden mit beigefügten Schrauben, Unterlagscheiben und Muttern befestigen.

2. Montage Fußstütze

- 2.1 Schraube im oberen Bereich der originalen Fußstütze entfernen.
- 2.2 TECHART Fußstütze auflegen und mit Schraube (3,9 x 25) oben befestigen. (4,8 x 19 bei RL Fußstütze)
- 2.3 Befestigungsloch unten bohren (2 mm) und mit Schraube (3,9 x 16) befestigen. (4,8 x 19 bei RL Fußstütze)



MOUNTING INSTRUCTIONS

MADE
IN
GERMANY

TECHART – Aluminum foot control TECHART – Aluminum footrest for Porsche 996 / 986



Art.No.: 086.460.400.009-01
Art.No.: 086.460.401.009
Art.No.: 086.460.402.009 (LHD)
Art.No.: 086.460.412.009 (RHD)

1. Assembly of pedals

- 1.1 Remove the original rubber lining from clutch, brake and accelerator pedal.
- 1.2 Position the TECHART- pedal screens on the original pedals, adjust it, mark the mounting holes and drill the holes. (5 mm)
- 1.3 Align the accelerator pedal screen at the upper and right edge of the original pedal; mark the mounting holes and bore them. (2 mm)
- 1.4 Fasten the pedal screens with attached screws, plain washers and nuts.

2. Assembly footrest

- 2.1 Remove the screw within the upper area of the original footrest.
- 2.2 Lay on the TECHART footrest and fasten it with attached screw 3.9 x 25. (4,8 x 19 for RHD footrest)
- 2.3 Bore the mounting hole (2 mm) downside of the TECHART footrest and fasten it also with attached screw 3.9 x 16. (4.8 x 19 for RHD footrest)





**Ausführung Rechtslenker /
version RHD**

